

Marin Rift Zone Jr 24"-Suspension Setup

REAR SHOCK SET UP

Recommended Sag = 30%/15mm

Step 1: Set correct pressure in rear shock.

Step 2: Sit on the bike and cycle the suspension (*with correct riding gear).

Step 3: Reset O-ring and sit on the bike, DO NOT BOUNCE, carefully step off.

Step 4: Measure sag (from o-ring to seal of shock), If it does not match the bike's recommended sag in millimeters repeat process.

Step 5: Adjust rebound setting to ensure proper control.

FORK SET UP

Marin recommends that all bikes front and rear suspension feel balanced

Step 1: After rear sag is set follow the recommended pressure from the fork manufacture.

Step 2: Bounce evenly up and down on the bike, cycling the suspension up and down to make sure both front and rear suspension feel balanced, if the front does not match the rear add or release pressure.

Step 3: Once the bike feels balanced adjust the rebound damping to ensure proper control.

X-Fusion O2 Pro R

Rider weight
and shock
setup

LBS	KG	PSI
40	18	40
50	23	50
60	27	60
70	32	70
80	36	80
90	41	90
100	45	100
110	50	110
120	54	120