

1. Remove two m8 security bolts from the tray end cap. Security bolts may be difficult to remove. If you are having trouble please visit a local Kuat dealer.

(koo-at)

- 2. Slide the end cap and lock assembly out of the tray.
- 3. Place ramp connection plate between the tray and end cap. Slide the lock assembly through the plate and re-intall the two m8 security bolts.



