

Reach	14	14.4	14.8	15.2	15.6
I - Tube de direction (°)	70.3	70.3	70.3	70.3	70.3
J - Tube de selle (°)	74	74	73	73	73
A - Tube de selle	18.5	19.3	20.1	21.1	22
B - Tube horizontal	20	20.6	21.7	22.4	23.1
C - Front Center	22.7	23.4	24.2	24.9	25.6
D - Trail	2.8	2.8	2.8	2.8	2.8
F - Déport de fourche	2	2	2	2	2
G - Bases	16.5	16.5	16.5	16.5	16.5
K - Tube de direction	4.4	5.4	6.4	7.4	8.4
L - Fourche	15.6	15.6	15.6	15.6	15.6
HAV	2.8	2.8	2.8	2.8	2.8