Marin Rift Zone 27.5" XR-Suspension Setup

REAR SHOCK SETUP

Recommended Sag = 30%/15mm

Step 1: Set correct pressure in rear shock.

Step 2: Sit on the bike and cycle the suspension (*with correct riding gear).

Step 3: Reset O-ring and sit on the bike, DO NOT BOUNCE, carefully step off.

Step 4: Measure sag (from o-ring to seal of shock), If it does not match the bike's recommended sag in millimeters repeat process.

Step 5: Adjust rebound setting to ensure proper control.

FORK SETUP

Marin recommends that all bikes front and rear suspension feel balanced

Step 1: After rear sag is set follow the recommended pressure from the fork manufacturer.

Step 2: Bounce evenly up and down on the bike, cycling the suspension up and down to make sure both front and rear suspension feel balanced, if the front does not match the rear add or release pressure.

Step 3: Once the bike feels balanced adjust the rebound damping to ensure proper control.

Fox Float X

Rider weight		
and shock setup		
	KG	
120	54	140
130	59	145
140	64	150
150	68	155
160	73	166
170	77	177
180	82	190
190	86	201
200	91	212
210	95	224
220	100	237
230	104	250
240	109	263
250	113	277
260	118	292
270	122	307