

# **Marin Rift Zone E2-Suspension Setup**

## **REAR SHOCK SETUP**

*Recommended Sag = 30%/19.5mm*

Step 1: Set correct pressure in rear shock.

Step 2: Sit on the bike and cycle the suspension (\*with correct riding gear).

Step 3: Reset O-ring and sit on the bike, DO NOT BOUNCE, carefully step off.

Step 4: Measure sag (from o-ring to seal of shock), If it does not match the bike's recommended sag in millimeters repeat process.

Step 5: Adjust rebound setting to ensure proper control.

## **FORK SETUP**

*Marin recommends that all bikes front and rear suspension feel balanced*

Step 1: After rear sag is set follow the recommended pressure from the fork manufacturer.

Step 2: Bounce evenly up and down on the bike, cycling the suspension up and down to make sure both front and rear suspension feel balanced, if the front does not match the rear add or release pressure.

Step 3: Once the bike feels balanced adjust the rebound damping to ensure proper control.

## **Fox Float X**

Rider weight  
and shock  
setup

<b>LBS</b>	<b>KG</b>	<b>PSI</b>
120	54	120
130	59	130
140	64	140
150	68	150
160	73	160
170	77	170
180	82	180
190	86	190
200	91	205
210	95	220
220	100	235
230	104	250
240	109	265
250	113	280
260	118	295
270	122	305