

REAR SHOCK SETUP

Recommended Sag = 30%/19.5mm

Step 1: Set correct pressure in rear shock.

Step 2: Sit on the bike and cycle the suspension (*with correct riding gear).

Step 3: Reset O-ring and sit on the bike, DO NOT BOUNCE, carefully step off.

Step 4: Measure sag (from o-ring to seal of shock), If it does not match the bike's recommended sag in millimeters repeat process.

Step 5: Adjust rebound setting to ensure proper control.

FORK SETUP

Marin recommends that all bikes front and rear suspension feel balanced

Step 1: After rear sag is set follow the recommended pressure from the fork manufacturer.

Step 2: Bounce evenly up and down on the bike, cycling the suspension up and down to make sure both front and rear suspension feel balanced, if the front does not match the rear add or release pressure.

Step 3: Once the bike feels balanced adjust the rebound damping to ensure proper control.

X-Fusion 02 PRO RXC

Rider weight and shock setup

LBS	KG	PSI
120	54	106
130	59	113
140	64	117
150	68	120
160	73	123
170	77	140
180	82	156
190	86	170
200	91	182
210	95	192
220	100	200
230	104	207
240	109	212
250	113	216
260	118	219
270	122	220