

REAR SHOCK SETUP

Recommended Sag = 30%/15mm

Step 1: Set correct pressure in rear shock.

Step 2: Sit on the bike and cycle the suspension (*with correct riding gear).

Step 3: Reset O-ring and sit on the bike, DO NOT BOUNCE, carefully step off.

Step 4: Measure sag (from o-ring to seal of shock), If it does not match the bike's recommended sag in millimeters repeat process.

Step 5: Adjust rebound setting to ensure proper control.

FORK SETUP

Marin recommends that all bikes front and rear suspension feel balanced

Step 1: After rear sag is set follow the recommended pressure from the fork manufacturer.

Step 2: Bounce evenly up and down on the bike, cycling the suspension up and down to make sure both front and rear suspension feel balanced, if the front does not match the rear add or release pressure.

Step 3: Once the bike feels balanced adjust the rebound damping to ensure proper control.

RockShox Deluxe Select RT

Rider weight and shock setup

<u>LBS</u>	<u>KG</u>	<u>PSI</u>
120	54	103
130	59	118
140	64	133
150	68	150
160	73	167.5
170	77	185
180	82	195
190	86	205
200	91	213
210	95	221
220	100	229
230	104	234
240	109	239
250	113	244
260	118	249
270	122	254