

## REAR SHOCK SETUP

*Recommended Sag = 30%/19.5mm*

Step 1: Set correct pressure in rear shock.

Step 2: Sit on the bike and cycle the suspension (\*with correct riding gear).

Step 3: Reset O-ring and sit on the bike, DO NOT BOUNCE, carefully step off.

Step 4: Measure sag (from o-ring to seal of shock), If it does not match the bike's recommended sag in millimeters repeat process.

Step 5: Adjust rebound setting to ensure proper control.

## FORK SETUP

*Marin recommends that all bikes front and rear suspension feel balanced*

Step 1: After rear sag is set follow the recommended pressure from the fork manufacturer.

Step 2: Bounce evenly up and down on the bike, cycling the suspension up and down to make sure both front and rear suspension feel balanced, if the front does not match the rear add or release pressure.

Step 3: Once the bike feels balanced adjust the rebound damping to ensure proper control.

## X-Fusion 02 PRO R

Rider weight and shock setup

LBS	KG	PSI
120	54	150
130	59	165
140	64	180
150	68	195
160	73	205
170	77	215
180	82	225
190	86	240
200	91	255
210	95	270
220	100	285
230	104	295
240	109	305
250	113	310
260	118	314
270	122	317