

REAR SHOCK SETUP

Recommended Sag = 30%/16.5mm

Step 1: Set correct pressure in rear shock.

Step 2: Sit on the bike and cycle the suspension (*with correct riding gear).

Step 3: Reset O-ring and sit on the bike, DO NOT BOUNCE, carefully step off.

Step 4: Measure sag (from o-ring to seal of shock), If it does not match the bike's recommended sag in millimeters repeat process.

Step 5: Adjust rebound setting to ensure proper control.

FORK SETUP

Marin recommends that all bikes front and rear suspension feel balanced

Step 1: After rear sag is set follow the recommended pressure from the fork manufacturer.

Step 2: Bounce evenly up and down on the bike, cycling the suspension up and down to make sure both front and rear suspension feel balanced, if the front does not match the rear add or release pressure.

Step 3: Once the bike feels balanced adjust the rebound damping to ensure proper control.

RockShox Super Deluxe Ultimate

Rider weight and shock setup

LBS	KG	PSI
120	54	109
130	59	119
140	64	130
150	68	141
160	73	152
170	77	164
180	82	176
190	86	188
200	91	200
210	95	213
230	104	239
240	109	252
250	113	266
260	118	280
270	122	294